

# Additional Work Necessary for installing a Motorized Shade



- ▶ A motorized shade must be installed
  - Squarely and untwisted (level Clips at each end).
- ▶ We request that the clip locations are marked, then measurements taken before ordering to insure correct size is ordered.
- ▶ Check Square-ness with a carpenter square
  - If it is not square shims will be necessary
- ▶ To insure shade is not twisted use a level on the clips at the head rail and the bottom rail.
- ▶ Make sure the shade is positioned in the skylight well so neither side can scrape up on the wall or get hung up in any way